

A	x86	B	x16	C	x56	D	x4	E	x4	F	x8	G	x10	H	x30	I	x2	J	x8	K	x2	L	x3	M	x4	N	x4
PARAFUSO 3,5x14 SCREW 3,5x14		PARAFUSO 3,5x40 SCREW 3,5x40		PREGO 10x10 NAIL		PARAFUSO MINIFIX		TAMBOR CAM LOCK		CANTONEIRA		JUNÇÃO		CAVILHA 6X30 WOOD DOWEL 6X30		PERFIL H		RODIZIO		TAPA FURO		DISTANCIADOR		DOBRADIÇA		CALÇO	

1º Passo
Pass / Paso / 1er étape

08 04 03 07 06 05

2X 2X 2X 2X 11/09 2X

Mini Fix

F	x8	L	x2	M	x4	N	x4	A	x28
D	x4	E	x4	H	x26				

2º Passo

Pass / Paso / 2er étape

3º Passo

Pass / Paso / 3er étape

4º Passo

Pass / Paso / 4er étape

J x8 A x48

5º Passo

Pass / Paso / 5er étape

A x2
L x1

6° Passo
Pass / Paso / 6er étape

Diagram illustrating the 6th step of assembly. The diagram shows the installation of the top shelf (13) and the back panel (14) onto the main frame (01, 02, 03, 04, 05, 06). The back panel is secured with screws (15) and a bracket (16). The top shelf is secured with screws (17) and a bracket (18). The diagram also shows the installation of the side panel (19) and the bottom panel (20).

7° Passo
Pass / Paso / 7er étape

Diagram illustrating the 7th step of assembly. The diagram shows the installation of the top shelf (13) and the back panel (14) onto the main frame (01, 02, 03, 04, 05, 06). The back panel is secured with screws (15) and a bracket (16). The top shelf is secured with screws (17) and a bracket (18). The diagram also shows the installation of the side panel (19) and the bottom panel (20).

8º Passo

Pass / Paso / 8er étape

Diagram illustrating the 8th step of assembly. The cabinet frame (06) is shown with the front panel (18) and the bottom panel (17) being attached. The front panel (18) is secured with screws (C) and the bottom panel (17) is secured with screws (G+C). A detail shows a 'Gx10' screw being used to secure the panels.

9º Passo

Pass / Paso / 9er étape

Diagram illustrating the 9th step of assembly. The cabinet frame (06) is shown with the door (07) being attached. The door (07) is secured with hinges (A) and the cabinet frame (06) is secured with screws (A). A detail shows a hinge being installed on the door (07) and the cabinet frame (06).