


EXPLODED VIEW: This diagram shows the individual components of the wardrobe system, numbered 01 through 31. It includes side panels (12, 13, 14), shelves (10, 11), drawers (15, 17), and various internal dividers and supports (02, 03, 04, 05, 06, 07, 08, 09, 10, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30). The exploded view illustrates how these parts fit together to form the wardrobe structure.

ASSEMBLED VIEW: This diagram shows the wardrobe system fully assembled. It features a main wardrobe unit with a height of 2400MM and a width of 2735MM. The unit has a depth of 613MM. The wardrobe unit is shown with a set of drawers (15, 17) and a set of shelves (10, 11). The drawers are labeled 15 and 17, and the shelves are labeled 10 and 11. The wardrobe unit is shown with a set of drawers (15, 17) and a set of shelves (10, 11). The drawers are labeled 15 and 17, and the shelves are labeled 10 and 11.

OPTIONAL CONFIGURATION: This diagram shows an optional configuration of the wardrobe system. It features a main wardrobe unit with a height of 2400MM and a width of 2735MM. The unit has a depth of 613MM. The wardrobe unit is shown with a set of drawers (15, 17) and a set of shelves (10, 11). The drawers are labeled 15 and 17, and the shelves are labeled 10 and 11. The wardrobe unit is shown with a set of drawers (15, 17) and a set of shelves (10, 11). The drawers are labeled 15 and 17, and the shelves are labeled 10 and 11.

97230 - 27/01/2025 - 420 X 400



P.4 - SUPORTE CABIDEIRO
COAT HANGER SUPPORT
SOPORTE PARA PERCHERO **x06**



CÓD.66522

U.5 - CABIDEIRO
COAT HANGER
PERCHERO **x03**



655MM
CÓD. 97226

Q.1 - DOBRADIÇA SLOW CURVA CALÇO FIXO
FRAME WING
BISAGRA **x24**



CÓD. 55304

Q.2 - DOBRADIÇA SLOW EASY ALTA
FRAME WING
BISAGRA **x08**



CÓD. 88891

A.3 - PARAFUSO 3,5X14MM
3,5X14MM SCREW
TORNILLO 3,5X14MM **x192**



CÓD.64725

W.13 - PUXADOR GR ERGON KIT C/08
GR ERGON HANDLE KIT W/08
KIT MANGO GR ERGON C/08 **x01**



2300X20 MM
CÓD. 96426 - AMEN CLEAN
CÓD. 96657 - FRASSINO

  **Sugestão da quantidade de pessoas necessárias para montagem.**
 Tip of the number of people required for product assembly.
 Consejo de la cantidad de personas necesarias para el armado de productos.

180min.

01

B.2+F.2
x03

A.10
x03

F.2 x03 B.2 x12 A.10 x03

01 PÉ OPCIONAL/ OPTIONAL FOOT/ PIE OPCIONAL

A.3+H.15
x08

H.15 x10 A.3 x40

02

A.3+H.7
x10

A.3 x10 H.7 x10

03

C.1
x04

C.1 x04

05

A.10
x08

S.1 x08 C.1 x04

A.10 x08 S.1 x08 C.1 x04

06

M.3
x24

M.3 x24

07

C.1
x08

C.1 x08

08

C.1
x04

C.1 x04

09

A.15
x08

A.5 x12

M.3+J.2 x04

Local onde será parafusado.
Local where have to be screwed.
Local donde deve ser atornillado.

M.3 x16 J.2 x01 A.15 x08 A.5 x12

10

A.15
x08

A.5 x12

ESQUERDO
LEFT
IZQUIERDO

DIREITO
RIGHT
DERECHO

FIXAR AS CORRETORES
FORMANDO UM PAR COM
OS DISTANCIADORES
ATTACH THE SLIDES
FORMING A PAIR WITH
THE DISTANCERS
AJUNTAR LAS DIPOSITIVAS
FORMAR UNA PAREJA CON
LOS DISTANCIADORES

A.15 x08 A.5 x12

11

C.1
x04

C.1 x04

12

C.1
x08

C.1 x08

13

C.1
x04

C.1 x04

14

C.1
x16

C.1 x16

15

C.1
x04

C.1 x04

16

S.5
x30

C.1
x04

C.1 x04 S.5 x30

17

O.2+A.3
x06

J.2 x01 M.3 x24

O.2 x06 A.3 x36 M.3 x24 J.2 x01

18

B.2+F.2
x02

F.2 x12 B.2 x48

19

A.3+P.1
x02

A.3 x12 C.1 x24 P.1 x12

20

W.6+A.8
x01

W.6 x06 A.8 x06

21

P.4+A.3
x06

P.4 x06 A.3 x12

22

K.1+L.7
x66

K.1 x184 L.7 x66

23

A.8
x04

A.8 x04

24

A.8
x12

A.8 x12 S.1 x20 A.10 x08

25

Q.1+A.3
x08

Q.2 x08 Q.1 x24 A.3 x64

**ESPELHO OPCIONAL 1100X344X3MM
1100X344x3MM OPTIONAL MIRROR
ESPEJO OPCIONAL 110X344X3MM**

A.4+P.7
x08

A.4 x08 P.7 x08

26

A.3+Q.2
x08

A.3+Q.1 x24

Q.1 x24 Q.2 x08 A.3 x128

27

A.7+W.13
x08

A.7 x48 W.13 x08

**Regulagem das dobradiças
Adjustment of hinges
Ajuste de bisagras**

A.7+W.13
x08

A.7 x48 W.13 x08

**OPÇÃO COM ESPELHOS
OPTION WITH MIRRORS
OPCIÓN CON ESPEJOS**

Y.1
x01

Y.1 x01