


INSTRUÇÃO DE MONTAGEM

Assembly Instruction / Instrucciones de montaje



TV stand with 2 doors

Ref.: 1552

TV stand with 2 doors / Mueble de TV con 2 puertas




2:00h




V.:01

Lista de peças Parts list / Liste de piezas


	QT.
01-TAMPO Top / Parte Superior	01
02-LADO ESQUERDO Left Side / Lado Izquierdo	01
03-LADO DIREITO Right Side / Lado Derecho	01
04-BASE Base / Base	01
05-DIVISÓRIA Divider / Divisor	01
06-PÉ FRONTAL Front Leg / Pata Delantera	02
07-PÉ TRASEIRO ESQUERDO Left Rear Leg / Pata Trasero Izquierdo	01
08-TRAVESSA LATERAL Side Crossbar / Travesaño Lateral	02
09-PÉ TRASEIRO DIREITO Front Crossbar / Travesaño Delantero	01
10-TRAVESSA SUPERIOR Upper Crossbar / Travesaño Superior	02
11-TRAVESSA FRONTAL Side Crossbar / Travesaño Delantero	01
12-PRATELEIRA Shelf / Estante	01
13-TRASEIRO Back / Parte Posterior	01
14-PORTA ESQUERDA Left Door / Puerta Izquierda	01
15-REFORÇO DE PORTA Door Reinforcement / Refuerzo De La Puerta	04
16-PORTA DIREITA Right Door / Puerta Derecha	01




01




02




03




04




05




06




07




08




09




10




11




12




13




14




15



16



17



18

