





















sienamóveis

AB 70

COZINHA MASTER

A		08
B		04
C		04
D		04
E		04
F		32
G		20
H		02
J		01
K		02
L		01
M		01



Fixação na parede

