


Manual de Montagem

Ax1



Bx1



Cx2



M8x30

Dx4




M6x20

Ex4



M6x25


Fx2




Gx1



①



②



③

