


HOME SOURCE[®]










www.homesourceind.com-sales@homesourceind.com





Assembly Instruction


Model: 154BRD (AR-130)
2 Door Pantry




PART LIST

① x 2 	④ x 1 	⑦ x 1 
② x 1 	⑤ x 1 	⑧ x 2 
③ x 1 	⑥ x 1 	⑨ x 2 


A x 14 	B x 6 	C x 24 	D x 2 
E x 2 	F x 14 	G x 14 	H x 50 
I x 8 	J x 1 	K x 5 	L x 1 




Step! 2




Step! 3




Step! 4




Step! 5



Step! 6



Safety Strap Guide Included



Wall Screws		Wall Plug		Furniture Screws	
A	01	B	01	F	01
C	01	D	02	E	01
J		L		I	