

MANUAL DE MONTAGEM
ASSEMBLY INSTRUCTIONS
INSTRUCCIONES DE ARMADO


Fellicci Indústria de Móveis Ltda.

Av. Alvi Azul, nº801 - Fones: +55(54)3452-4400 / +55(54)3451-6329

CEP:95707-300 - Bento Gonçalves/RS Site: www.fellicci.com.br - E-mail: engenharia@fellicci.com.br



RAC28-RACK TV BEATRIZ
RAC28-ESTANTE DE LA TELE BEATRIZ



Ferragens / Accessories / Accesorios


A		20
B		02
C	 Screw minifix Tornillo minifix	14
D		44
E	 Grab minifix Tambor minifix	14
F		40
G		10
H		01
J		06
K		01
L		10
M		01
N		04
O		02
P		10
Q		02

Lista de Peças / Part List / Lista de piezas


CÓD	DESCRIÇÃO	DESCRIPTION	DESCRIPCIÓN	DIMENSÕES DIMENSIONS DIMENSIONES (mm)	QTD QTY Quant
01	Lateral Direita	Right Side	Lateral Derecha	600x380x15	1
02	Lateral Esquerda	Left Side	Lateral Izquierda	600x380x15	1
03	Divisória	Division	División	365x344x15	2
04	Divisória	Division	División	158x298x15	2
05	Porta	Door	Puerta	359x600x15	1
06	Tampo	Top	Tapa	1802x380x15	1
07	Base Inferior	Bottom Base	Base Inferior	1770x380x15	1
08	Base Central	Central Base	Base Central	1770x380x15	1
09	Travessa	Crossbar	Travessaño	1801x62x15	2
10	Costa	Back	Revés	1790x176x03	1
11	Costa	Back	Revés	1790x382x03	1

VOCÊ VAI PRECISAR DE / YOU WILL NEED / USTED NECESITARÁ


Ferramentas não fornecidas / Tools not supplied / Herramientas no incluidas




Chave Phillips
Screwdriver Phillips
Destornillador cruz



Trena
Measuring tape
Cinta de medición



Martelo
Hammer
Martillo



Furadeira
Drill machine
Taladro

