


MANUAL DE INSTRUÇÕES



A=Backrest x1 	I=Screw(M6X25mm) x6
B=Cushion x1 	J=Screw(M6X20mm) x6
C=Armrest x2 	K=Spacer(M6X18mm) x6
D=Silver-Cover x2 	L=Spacer(M6X14mm) x6
E=Mechanism x1 	M=Spanner x1
F=Gaslift x1 	
G=Disk Base x1 	
H=Castor x5 	