









USER'S MANUAL(3 seats series)



Step4

Seral number	Parts name	Quantity
1	M8*8 Screw	24
2	Support	6
3	Seat	3
4	Beam	1
5	M8*13 Screw	12
6	M10*100 Screw	4
7	Leg	2
8	Adjusts the foot	4
9	Armrest	2
10	M6 Hexagonal screw tap	1
11	M8 Hexagonal screw tap	1
12	Cannula	1

USER'S MANUAL(3 seats series)



Step4

Seral number	Parts name	Quantity
1	M8*8 Screw	24
2	Support	6
3	Seat	3
4	Beam	1
5	M8*13 Screw	12
6	M10*100 Screw	4
7	Leg	2
8	Adjusts the foot	4
9	Armrest	2
10	M6 Hexagonal screw tap	1
11	M8 Hexagonal screw tap	1
12	Cannula	1