


INSTRUÇÃO DE MONTAGEM

Assembly Instruction / Instrucciones de montaje




Vitrine 2 Portas 1 Gavetas Rubi

Cupboard 2 doors 1 drawer / Vitrina 2 Puertas 1 cajón

Ref.: 8932



90 min.




Lista de peças Parts list / Liste de piezas

	QT.
1-Chapeu Top / Tapa superior	01
2-Prateleira Shelf / Estantes	02
3-Base Base / Base	01
4-Lateral esquerda Left side / Lateral izquierdo	01
5-Lateral direita Right side / Lateral derecho	01
6-Aplique Apply / Aplicar	01
7-Pé Feet / Pies	04
8-Porta Doors / Puertas	02
9-Frente de gaveta Drawer front / Frente cajon	01
10-Traseiro de gaveta Drawer back / Traseiro cajon	01
11-Lateral esquerda de gaveta Drawer left side / Lateral izquierdo cajon	01
12-Lateral direita de gaveta Drawer right side / Lateral derecho cajon	01
13-Fundo de gaveta Back drawer / Trasero cajon	01
14-Forro traseiro superior Upper back panel / Panel trasero superior	04
15-Encosto de porta Door backrest / Respaldo puerta	01
16-Corrediças Drawer runner / Carril metalico	01
17-Vidro Glass / Vidrio	04
18-Forro traseiro inferior Lower back panel / Panel trasero abajo	01
19-Prateleira fixa Fixed shelf / Estante fijo	01
20-Prateleira inferior Bottom shelf / Estante abajo	01

V.:11


A 8.0 x 25 42x	B 4.0 x 25 15x	C M4 x 22 04x	D 04x	E 10 x 10 60x	F 70 x 50 4x	H 3.5 x 12 36x	I 4 x 40 15x	K 06x	
L 06x	M 16x	N 20x	O 10x	P 08x	Q 3 x 16 45x	R 4,5 x 50 1x	S 2x	T 1x	U Fita anti tombamento 1x

1



2

Nesta posição de corredeira levante a alavanca, do contrario abaixe.
 In this sliding position, raise the lever, otherwise lower it.
 En esta posición deslizante, levante la palanca, de lo contrario bájela.




Desprenda as corredeiras (A) do aramado. Depois levante a alavanca de separação da PARTE-1 da corredeira e desconecte-a


Detach the slides (A) from the wire. Then lift the slide PARTE-1 separation lever and disconnect it

Separar las correderas (A) del cable. Luego levante la palanca de separación deslizante PARTE-1 y desconéctela


3




4




5




6




7




8




9




10



11




12




1


13




14




15



16



17



18

